

2002-2008 CRV Maintenance Schedule for Severe Conditions

<u>3,750mi/ 6 months</u> <u>Do items in A.</u>	A: ____ Replace oil filter and engine oil with synthetic blend oil.
<u>7,500mi/ 6 months</u> 1 <u>Do items in A and B.</u>	B: ____ Rotate tires--Check tire pressure and condition ____ Inspect front and rear brakes. *Check pads and discs for wear (thickness), damage, and cracks. *Check calipers for damage and leaks, and tightness of mount bolts. *Check brake linings for cracking, glazing, wear or contamination. ____ Inspect tie-rods ends and boots. *Check steering linkage. *Check boots for damage and leaking grease. *Check fluid lines for damage and leaks. ____ Inspect suspension components. *Check condition of ball joint boots for cracks and bands for tightness. ____ Top off washer fluid
<u>11,250mi/ 1year</u> <u>Do items in A.</u>	
<u>15,000mi/ 1year</u> 2 <u>Do items in A,B,D</u>	
<u>18,750mi/ 1 ½ years</u> <u>Do items in A.</u>	
<u>22,500mi/ 1 ½ years</u> 1 <u>Do items in A and B.</u>	
<u>26,250mi/ 2 years</u> <u>Do items in A.</u>	
<u>30,000mi/ 2 years</u> 3 <u>Do items in A,B,C,D,E</u>	
<u>33,750mi/ 2 ½ years</u> <u>Do items in A.</u>	
<u>37,500mi/ 2 ½ years</u> 1 <u>Do items in A and B.</u>	
<u>41,250mi/ 3 years</u> <u>Do items in A.</u>	
<u>45,000mi/ 3 years</u> 2.5 <u>Do items in A,B, D</u> <u>Replace coolant</u>	
<u>48,750mi/ 3 ½ years</u> <u>Do items in A.</u>	C: ____ Check parking brake adjustment to factory specifications. ____ Lubricate all hinges, locks and latches. ____ Inspect brake hoses and lines (including ABS). Check the master cylinder and ABS modulator for leaks and damage. ____ Check all fluid levels and condition of fluids; check for leaks. Top off fluids if necessary. ____ Inspect cooling system hoses and connections. ____ Add fuel system cleaner. ____ Replace Brake fluid. ____ Inspect exhaust system. Check catalytic convertor heat shield, exhaust pipe, and muffler for damage, leaks, and tightness. ____ Inspect fuel lines and conenctions. Check for loose connections, cracks, and deterioration; retighten loose connections. ____ Check all lights. Check function of all interior and exterior lights. ____ Replace Manual Transmission Fluid. Use Honda Manual Fluid.
<u>52,500mi/ 3 ½ years</u> 1 <u>Do items in A and B.</u>	
<u>56,250mi/ 4 years</u> <u>Do items in A.</u>	
<u>60,000mi/ 4 years</u> 3.5 <u>Do items in A,B,C,D,E and F</u>	
<u>63,750mi/ 4 ½ years</u> <u>Do items in A.</u>	
<u>67,500mi/ 4 ½ years</u> 1 <u>Do items in A and B.</u>	
<u>71,250mi/ 5 years</u> <u>Do items in A.</u>	
<u>75,000mi/ 5years</u> 2 <u>Do items in A,B,D</u>	
<u>78,750mi/ 5 ½ years</u> <u>Do items in A.</u>	
<u>82,500mi/ 5 ½ ears</u> 1 <u>Do items in A and B.</u>	
<u>86,250mi/ 6 years</u> <u>Do items in A.</u>	D: ____ Inspect and adjust drive belt. *Alternator, compressor belt: Inspect auto tensioner indicator. *P/S pump belt: Look for cracks and damage. ____ Replace transmission fluid using Honda ATF-Z1. ____ Replace A/C micron filter. ____ Replace the wiper inserts ____ Replace engine Air Filter.
<u>90,000mi/ 6 years</u> 4 <u>Do items in A, B, C, D, E.</u> <u>Replace coolant</u>	
<u>93,750mi/ 6 ½ years</u> <u>Do items in A.</u>	
<u>97,500mi/ 6 ½ years</u> 1 <u>Do items in A and B.</u>	
<u>101,250mi/ 7 years</u> <u>Do items in A.</u>	
<u>105,000mi/ 7 years</u> 5 <u>Do items in A,B,D,G,H</u>	
<u>108,750mi/ 7 ½ years</u> <u>Do items in A.</u>	
<u>112,500mi/ 7 ½ years</u> 1 <u>Do items in A and B.</u>	
<u>116,250mi/ 8 years</u> <u>Do items in A.</u>	
<u>120,000mi/ 8 years</u> 3.5 <u>Do items in A,B,C,D,E, F</u>	
ADDITIONAL NOTES:	E: ____ Replace the Rear Differential Fluid. Use Honda Dual Pump Fluid (4WD). F: ____ Replace serpentine belt. G: ____ Adjust valves to factory specifications and replace valve cover gasket. H: ____ Replace platinum spark plugs.
Service Advisor _____	
Technician _____	
RO# _____	